

## 'SNAP CAP' Cylinder Safety Cap Instructions for Use

1. Verify that the cylinder valve is closed prior to installation. Remove the lock. Screw the cap to cover all cylinder threads. Unscrew only far enough to align the valve port with the Snap Cap slot.
2. Tighten the setscrew against the neck ring.
3. Attach gauges. Lower the cover into position.
4. Always make sure the valve is completely closed prior to closing and locking the Snap Cap.

Always have Snap Cap closed and locked during transport. Check with your local authority having jurisdiction for your laws regarding transportation with the valve attached.



Part Number G-2501

6.5"x 3-1/8 x 11UN, High Pressure Fine Thread

Part Number G-2502

6.5"x 3-1/2 x 11UN, Low Pressure Fine Thread

Part Number G-2503

6.5"x 3-1/8 x 11UN, High Pressure Course Thread

Part Number G-2504

6.5"x 3-1/2 x 11UN, Low Pressure Course Thread

**Padlock Included**

**FIRST**  
First Safety Corporation  
(800) 436-7728  
Website: [www.firstsafety.com](http://www.firstsafety.com)